USER'S MANUAL

MAGNA-JET® for HydroBaths



MAGNA-JET®

Control Box

CLEAN- RELIABLE- WORRY FREE

When using electrical equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read and follow all instructions before using the equipment
2. Do not play with the magnetic impellers
3. Do not place the magnetic impellers close to each other
4. Keep the cord out of heavy traffic area. To avoid fire hazard NEVER put the cord under rugs, near heat generating devices
5. Always turn off the equipment before servicing
6. Do not drop or insert any object into any openings
7. Do not operate any equipment with a damaged parts
8. Any other use not recommended by the manufacturer may electrical shock or injury to persons
9. Never use outdoors
10. Do not attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void the warranty.

After reading this owner's guide, if you have any questions or comments, please call +1-817-633-1080 or contact our technical support department at support@luraco.com or visit our website at www.luraco.com for more information

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

FEATURES - OPERATIONS

MAGNA-JET Features

- Powerful massage Jet-streams
- Jet assembly can be detached from the pump for quick cleaning and sanitizing
- Built-in electronics sensor for pump control
- Long life AC motor
- Low power consumption
- Thermally protected
- Compatible with VSC which controls up to 12 JETs.
- Built-in controlled port for color light

MAGNA-JET System Installation

1. Determine the surface of the tub that you want to install the unit, ensure that the surface is flat
2. Locate a position to drill a hole with the dimensions as shown in Fig. 1
3. Insert the unit into the hole from inside the tub
4. **Use a hand screwdriver to tighten the four screws**
5. Plug the power cord of the unit into the Magna-JET Sensor/Control Box



Figure 1. Drill Instruction

Figure 2. Power cord must be in up position as shown above

Cleaning Instructions

1. Ensure the unit is off and clean the JET head one at a time
2. Use the key to remove the JET head from system (Please refer to figure 2 below)
3. Use anti bacterial solution to clean and sanitize all the plastic parts
4. Reassemble the system

Step 1: Insert the key and rotate it to the locking position **Step 2: Pull to remove the JET head**

Figure 3. JET Head Removal Instruction

WARRANTY INFORMATION

One (1) YEAR LIMITED WARRANTY

1. This Warranty applies only to the original purchaser of this product.
2. This Warranty applies ONLY to repair or replacement of any supplied or manufactured parts of this product. The warranty does not cover normal wear, coating, dropped or abused unit.
3. Unless otherwise proscribed by law, The LURACO technologies, Inc. shall not be liable for any personal injury, property or any incidental or consequential damages of any kind resulting from malfunctions, defects, misuse, improper installation or alteration of this product.

Attention: Any modification to the MAGNA-JET without our instruction will void the warranty

Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, LURACO Technologies does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

In no event shall LURACO Technologies be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, LURACO Technologies' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of LURACO Technologies.

Right to make changes — LURACO Technologies reserves the right to make changes to the product and information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — LURACO Technologies products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an LURACO Technologies' product can reasonably be expected to result in personal injury, death or severe property or environmental damage. LURACO Technologies accepts no liability for inclusion and/or use of LURACO Technologies products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

THANK YOU FOR BUYING LURACO TECHNOLOGIES' PRODUCTS

LURACO TECHNOLOGIES, INC.
1132 107TH STREET
ARLINGTON, TX 76011
TEL: +1-817-633-1080
FAX: +1-817-633-1085
WWW.LURACO.COM